

NEW!

Plastic Wire Bushings for Class 2 Wire

The attractive way to install low voltage wire through drywall



Get a great-looking job and easy, smooth insertion of cable through drywall with Arlington's new plastic **WIRE BUSHINGS!**

Offered in four sizes, these bushings offer quick installation




Make opening in drywall with a hole saw or drill bit

with a drill bit or a hole saw – and easy entry and exit of low voltage cable or speaker wire through drywall.

- Finishes cut edges of opening in drywall – looks better than an unfinished opening
- Paintable white plastic
- Four hole sizes:
 - WB500** .500"
 - WB875** .875"
 - WB112** 1.125"
 - WB200** 2.0"



1 Make opening the desired size



2 Unfinished opening in drywall



3 Insert bushing



4 Tighten with channel lock pliers

CATALOG NUMBER	UPC/DCI/NAED MFG #01 8997	HOLE SIZE*	SIZE OF OPENING	STD PKG
WB500	52950	0.500	.43	100
WB875	52951	0.875	.75	100
WB112	52952	1.125	1.00	50
WB200	52953	2.00	1.875	50

* Drill bit or hole saw size

The attractive way to finish cut edges of drywall!

Arlington

1 Stauffer Industrial Park
Scranton, PA 18517
800/233.4717
Fax 570/562.0646
www.aifittings.com
www.arlnew.com/wb